

STT 3000 (Series STT350, STT250 and STT150)

Supplementary Accessories & Kits

STT-15U Issue 3

Honeywell Confidential & Proprietary

Kit Description		Equivalent Transmitter Option	Kit Number
Electronics Module			
Order as model number from Model Selection Guide 34-44-16-02 (STT350).			
Order as model number from Model Selection Guide 34-44-16-03 (STT250).			
Order as model number from Model Selection Guide 34-44-16-06 (STT150).			
Field Mount Housings for STT350, STT250 and STT150.			
Field Mount	Aluminum with baked on beige polyester/epoxy hybrid paint		51204230-001
Housing Base	Aluminum with beige epoxy paint		51204230-002
Field Mount	STT350 Alum. with baked on beige polyester/epoxy hybrid paint		30752008-501
Housing End Cap (no window)	STT250 Alum. with baked on beige polyester/epoxy hybrid paint		30752006-501
Field Mount	STT350 Long Alum. Meter Cap		30756369-501
Housing Meter Cap (with window)			
Housing End Cap (with window)	STT250 Alum. With baked on beige polyester/epoxy hybrid paint		30755956-501
STT350 Housing Base and End Cap Kits (no module, meter, spacer ring or nameplate)			
Alum. with baked on beige polyester/epoxy hybrid paint	STT350 Table II, EP __		30749634-002
Aluminum with beige epoxy paint	STT350 Table II, XC __		30749634-003
Aluminum with red epoxy paint	STT350 Table VI, ST02		30749634-004
STT250 and STT150 Head Mount Housings			
Aluminum (1/2" NPT Sensor and Cable/ Conduit Entries)	Table II, CN _		51452348-502
Aluminum (1/2" NPT Sensor and M20x1.5 Cable Entries)	Table II, CM _		51452348-504
Meters (For use with Field Mount Housing)			
Replacement Smart Meter			30757178-501
Replacement Analog Meter			30756997-501
Replacement EU Meter			51451985-501
Meter Mounting Bracket Kit (plastic)			46188056-502
Diode for Analog Meter			46188067-001

Kit Description	Equivalent Transmitter Option	Kit Number
Miscellaneous Parts		
Transient Protector for STT 3000 (external)*	STT350/ 35F Table IV, ___ LP __;	30755970-501
	STT250 Table IV, __ L.	30755970-501
Surge Protector for STT350/ 35F (internal)	STT350/ 35F Table IV, ___ SP __;	46188074-501
Surge Protector for STT250/ 150 (internal)	STT250 Table IV, __ S.	46188660-501
	STT150 Table IV, __ S	46188660-501
Adapter Plate to Mount STT250 Module in Field Mount Housing	----	46188423-501
Carbon Steel Mounting Bracket for 2-inch pipe* (For use with Field Mount Housing)	STT350 Table IV, MB _____; STT250 Table IV, M __.	30755905-001
Stainless Steel Mounting Bracket for 2-inch pipe* (For use with Field Mount Housing)	STT350 Table IV, SB _____; STT250 Table IV, S __.	30671907-001
316SS Conduit Adapter - M20 connection (EEx d IIC approved)	STT350 Table IV, __ 1 _____; STT250 Table IV, _ 1 _.	51202409-001
316SS Conduit Adapter - 3/4" NPT connection	STT350 Table IV, __ 3 _____; STT250 Table IV, _ 3 _.	51196567-001
SS Customer I.D. Tag (4 lines of 28 characters per line of customer specified information or blank)	STT350 Table III, __ TG and __ TB; STT250 Table III, _ T _ and _ B _.	51196566-001
DIN Rail Kit for STT350 (2 Clips and 2 Screws)*	STT350 Table IV, DR _____	46188055-502
DIN Rail Kit for STT250 (Clip, Adapter, Screws)*	STT250 Table IV, D __	46188431-501
DIN Rail Kit for STT150 (10 sets)	STT150 Table IV, D __	46188618-502
DIN Rail Kit for STT150 (1 set)		46188618-501
Spring Loading kit for STT250 (2 screws/springs)	STT250 Table IV, L __	46188617-501
Spring Loading kit for STT150 (2 screws/ springs)	STT150 Table IV, L __	46188617-501
Spring Loading kit for STT150 (20 screws/ springs)	STT150 Multi-Pack accessory	46188617-502

Literature		
(see 13:STT-OE-7 for ordering information)		
STT350 Specification and MSG		EN0I-5222
STT350 European Operator's Manual (English)	STT350 Table IV, _____ EN	EN1I-6162
STT350 French Operator's Manual	STT350 Table IV, _____ FR	FR1I-6162
STT350 Spanish Operator's Manual	STT350 Table IV, _____ SP	SP1I-6162
STT35F Fieldbus Operator's Manual (English)	STT35F Table IV, _____ EF	EN1I-6196
STT250 Specification and MSG	-	EN0I-6031
STT250 Operator's Manual (English)	STT250 Table III, __ E	EN1I-6190
STT250 Operator's Manual (French)	STT250 Table III, __ F	FR1I-6190
STT250 Operator's Manual (Spanish)	STT250 Table III, __ S	SP1I-6190
STT250 Operator's Manual (Chinese)	STT250 Table III, __ C	CH1I-6190
STT150 Specification (English)	-	EN0I-6063
STT150 Specification (French)	-	FR0I-6063
STT150 Specification (German)	-	GE0I-6063
STT150 Specification (Italian)	-	IT0I-6063
STT150 Specification (Spanish)	-	SP0I-6063
STT150 Operators Manual included in SCT 3000 CD ROM (in English, French German, Spanish & Italian)	-	

Next Page Blank

This page is intentionally left blank.